



2010 Ford EXPEDITION

Click to download a complete RV & Trailer Towing Guide.



Expedition and Expedition EL (extended length) are perfect for big adventures, with seating for up to eight passengers and towing of up to 9,200 pounds when properly equipped. Look to Expedition when you need it BIG.

KEY FEATURES

- Standard 5.4L SOHC V8 generating 310 hp and 365 lb.-ft. of torque, mated to 6-speed automatic transmission
- Class-leading 9,200-lbs. trailer towing capacity (8,900 lbs. for Expedition EL)
- Standard 4-wheel disc Anti-lock Brake System (ABS)
- New standard Trailer Sway Control works with standard AdvanceTrac® with RSC® (Roll Stability Control™)(b) to detect trailer sway, then automatically reacts to help maintain control of both the vehicle and the trailer(c)
- First-in-class independent rear suspension features refined, second generation architecture for improved ride and handling
- First-in-class, available PowerFold™ 3rd-row seat and 2nd-row CenterSlide™ feature for improved cargo area utility
- New standard MyKey™ owner controls feature lets you program ignition keys with specific parameters to help encourage smart driving habits, such as buckling up and traveling at appropriate speeds

(b) Designed to help in real-world situations, such as making emergency maneuvers or driving on slippery or uneven surfaces, this system features a vehicle-roll motion sensor in addition to AdvanceTrac's ABS, traction control and yaw control. RSC uses the sensor to directly measure the vehicle's roll rate at least 100 times every second, which helps determine when and how the system will apply individual brakes and modify engine power to help keep all four wheels firmly planted.

(c) Remember that even advanced technology cannot overcome the laws of physics. It is always possible to lose control of a vehicle due to inappropriate driver input for the conditions.

FRONTAL AREA CONSIDERATIONS

Vehicle Line	Frontal Area Limitations/ Considerations	
	Base Vehicle Frontal Area	With
Expedition	60 sq. ft.	5.4L V8 Engine Without Heavy-Duty Trailer Tow Package With Trailer Tow Package Class III/IV

FRONTAL AREA is the total area in square feet that a moving vehicle and trailer exposes to air resistance. The chart shows the limitations that must be considered in selecting a vehicle/trailer combination. Exceeding these limitations may significantly reduce the performance of your towing vehicle. Selecting a trailer with a low-drag, rounded front design will help optimize performance and fuel economy.

EXPEDITION STANDARD TOWING EQUIPMENT & TRAILER TOWING PACKAGES

Model (Option Code)	Expedition (Std.)	Expedition (536)
7-Wire Harness & 4/7-Pin Connector	-	X
Trailer Wiring Harness (4-Pin)	X	-
Hitch Receiver	X	(Std.)
Aux. Auto Trans. Oil Cooler	X(a)	X(a)
Heavy-Duty Flashers	X	(Std.)
Radiator Upgrade	-	X
Electronic Brake Wiring Kit	-	X
Trailer Sway Control	(Std.)	(Std.)

(a) 7-channel standard; 14-channel with 536 option package.

Notes: • Content may vary depending on model, trim and/or powertrain. See your Dealer for specific content information

• Trailer Towing Package recommended for all light trucks that will be used for towing to help ensure easy, proper connection of trailer lights

Required Trailer Towing Equipment

Includes items that must be installed.* Your New Vehicle Limited Warranty (see your dealer for a copy) may be voided if you tow without them.

Expedition

- For Trailers Over 6,000 Pounds – Heavy-Duty Trailer Tow Package

*Check with your dealer for additional requirements and restrictions.

2010 TRAILER TOWING SELECTOR



EXPEDITION

Engine	Axle Ratio	GCWR (Lbs.)	Maximum Loaded Trailer Weight (Lbs.) – Automatic Transmission			
			Expedition		Expedition EL	
			4x2	4x4	4x2	4x4
5.4L SOHC V8	3.31	11,800	6,000	–	–	–
		12,000	–	6,000	–	–
		15,000(1)	9,200	8,900	–	–
	3.73	11,800	6,000	–	–	–
		12,000	–	6,000	–	–
		12,100	–	–	6,000	–
		12,300	–	–	–	6,000
		15,000(1)	9,200	8,900	8,900	8,700
		15,100(1)	9,200	8,900	–	–

(1) Requires optional Heavy-Duty Trailer Tow Package.

Note: Trailer tongue load weight should be 10-15% of total loaded trailer weight. Make sure vehicle payload (reduced by option weight) will accommodate trailer tongue load weight and weight of passengers and cargo added to towing vehicle. Addition of trailer tongue load weight and weight of passengers and cargo cannot cause vehicle weights to exceed rear GAWR or GVWR. These ratings can be found on the vehicle Safety Compliance Certification Label.

Hitch Receiver Weight Capacity

The maximum weight capacities for the weight-distributing hitch receivers shown below may exceed the maximum loaded trailer weight for the vehicle specified. Refer to the Trailer Towing Selector chart for Maximum Loaded Trailer Weight for this vehicle.

Vehicle	Weight-Carrying Max. Trailer Capacity (Lbs.) ⁽¹⁾	Max. Tongue Load (Lbs.)	Weight-Distributing Max. Trailer Capacity (Lbs.) ⁽¹⁾	Max. Tongue Load (Lbs.)
Hitch Receiver:				
Expedition	6,000	600	9,200	920
Expedition EL	6,000	600	8,900	890

(1) Hitch receivers do not include a hitch ball or ball mounting. The vehicle owner is responsible for obtaining the proper hitch ball, ball mounting, weight distributing equipment (i.e., equalizing arms and snap-up brackets, sway control system) and other appropriate equipment to tow both the trailer and its cargo load.

Factory-Installed Trailer Hitch Receiver Option

- **Expedition:** Standard

Note: See chart above for the weight-carrying and weight-distributing capacities of these hitch receivers. (These capacities also are shown on a label affixed to each receiver.)

The vehicle owner is responsible for obtaining the proper hitch ball, ball mounting, weight-distributing equipment (i.e., equalizing arms and snap-up brackets, sway control system) and other appropriate equipment to tow both the trailer and load that will be towed.

How to Find Your Truck's Axle Ratio

If you do not know the axle ratio of your vehicle, check its Truck Safety Compliance Certification Label (located on the left front door lock facing or the door latch post pillar). Below the bar code, you will see the word AXLE and a two-digit code. Use this chart to find the axle ratio that corresponds to that code:

Vehicle	Rear Axle Ratio	Non-Limited Slip Rear Axle Code	Limited Slip Rear Axle Code
Expedition	3.31	15	Not Available
	3.73	16	H6

What to KNOW Before You Tow

Before You Buy

If you are selecting a vehicle that will be used for towing, you should determine the approximate weight of the trailer you intend to tow, including the weight of any additional cargo and fluids that you will be carrying in the trailer. Also be sure the vehicle has the proper optional equipment. Keep in mind that performance can be severely compromised in hilly terrain when minimum acceptable powertrain combination is selected. Consider purchasing a vehicle with a more powerful engine.

BRAKES

Many states require a separate braking system on trailers with a loaded weight of more than 1,500 pounds. For your safety, Ford Motor Company recommends that a separate functional brake system be used on any towed vehicle, including those dolly-towed or towbar-towed. There are two basic types of brake systems designed to activate trailer brakes:

- 1. Electronically Controlled Brakes** usually provide automatic and manual control of trailer brakes. They require that the tow vehicle be equipped with a controlling device and additional wiring for electrical power. These brakes typically have a control box installed within reach of the driver and can be applied manually or automatically.
- 2. Surge Brakes** are independent hydraulic brakes activated by a master cylinder at the junction of the hitch and trailer tongue. They are not controlled by the hydraulic fluid in the tow vehicle's brake system, and the tow vehicle's hydraulic system should never be connected directly to the trailer's hydraulic system.

Be sure your trailer brakes conform to all applicable state regulations. See *Quick Tips – Safe Trailering* on back cover for additional braking information.

TRAILER LAMPS

Make sure the trailer is equipped with lights that conform to all applicable government regulations. The trailer lighting system should not be connected directly to the lighting system of the vehicle. See a local recreational vehicle dealer or rental trailer agency for correct wiring and relays for the trailer and heavy-duty flashers.

After You Buy

Before heading out on a trip, check your vehicle's Owner Guide for break-in and severe-duty maintenance schedules (do not tow a trailer until your vehicle has been driven at least 500 miles). Be sure to have your fully loaded vehicle (including passengers) and trailer weighed so as not to exceed critical weight limits. If any of these limits are exceeded, cargo should be removed from the vehicle and/or trailer until all weights are within the specified limits.

SAFETY CHAINS

- Always use safety chains when towing. Safety chains are used to retain connection between the towing and towed vehicle in the event of separation of the trailer coupling or ball
- Use cross chains under the trailer tongue to prevent the tongue from contacting the ground if a separation occurs. Allow only enough slack to permit full turning – be sure they do not drag on the pavement
- When using a frame-mounted trailer hitch, attach the safety chains to the frame-mounted hitch using the recommendations supplied by the hitch manufacturer
- See your vehicle's Owner Guide for safety chain attachment information
- For rental trailers, follow rental agency instructions for hookup of safety chains

TRAILER WIRING HARNESS

- Some vehicles equipped with a factory-installed Trailer Tow Package include a trailer wiring harness and a wiring kit
- This kit includes one or more jumper harnesses (to connect to your trailer wiring connector) and installation instructions



QUICK TIPS

SAFE TRAILERING

Towing a trailer is demanding on your vehicle, your trailer and your personal driving skills. Follow some basic rules and you'll tow more safely and have a lot more fun.

WEIGHT DISTRIBUTION

- For optimum handling and braking, the load must be properly distributed
- Keep center of gravity low for best handling
- Approximately 60% of the allowable cargo weight should be in the front half of the trailer and 40% in the rear (within limits of tongue load or king pin weight)
- Load should be balanced from side-to-side to optimize handling and tire wear
- Load must be firmly secured to prevent shifting during cornering or braking, which could result in a sudden loss of control

BEFORE STARTING

- Before setting out on a trip, practice turning, stopping and backing up your trailer in an area away from heavy traffic
- Know clearance required for trailer roof
- Check equipment (make a checklist)

BACKING

- Back up slowly, with someone spotting near the rear of the trailer to guide you
- Place one hand at bottom of steering wheel and move it in the direction you want the trailer to go
- Make small steering inputs – slight movement of steering wheel results in much greater movement in rear of trailer

TURNING

When turning, be sure to swing wide enough to allow trailer to avoid curbs and other obstructions.

BRAKING

- Allow considerably more distance for stopping with trailer attached
- Remember, the braking system of the tow vehicle is rated for operation at the GVWR, not GCWR
- If your tow vehicle is a F-150, F-Series Super Duty®, or E-Series and your trailer has electric brakes, the optional Trailer Brake Controller (TBC) will help assure smooth, effective trailer braking by automatically proportioning the trailer braking to that of the towing vehicle
- If your trailer starts to sway, apply brake pedal gradually. The sliding lever on the TBC should be used only for manual activation of trailer brakes when adjusting the gain. Misuse, such as application during trailer sway, could cause instability of trailer and/or tow vehicle

TOWING ON HILLS

- Downshift the transmission to assist braking on steep downgrades and to increase power (reduce lugging) when climbing hills
- With TorqShift® transmission, select Tow/Haul mode to automatically eliminate unwanted gear search when going uphill and help control vehicle speed when going downhill

PARKING WITH A TRAILER

Whenever possible, vehicles with trailers should not be parked on a grade. However, if it is necessary, place wheel chocks under the trailer's wheels, following the instructions below.

- Apply the foot service brakes and hold
- Have another person place the wheel chocks under the trailer wheels on the downgrade side
- Once the chocks are in place, release brake pedal, making sure the chocks will hold the vehicle and trailer
- Apply the parking brake
- Shift automatic transmission into Park, or manual transmission into Reverse
- With 4-wheel drive, make sure the transfer case is not in Neutral (if applicable)

STARTING OUT WHEN PARKED ON A GRADE

- Apply the foot service brake and hold
- Start the engine with transmission in Park (automatic) or Neutral (manual)
- Shift the transmission into gear and release the parking brake
- Release the brake pedal and move the vehicle uphill to free the chocks
- Apply the brake pedal while another person retrieves the chocks

ACCELERATION AND PASSING

The added weight of the trailer can dramatically decrease the acceleration of the towing vehicle – exercise caution.

- When passing a slower vehicle, be sure to allow extra distance. Remember, the added length of the trailer must clear the other vehicle before you can pull back in
- Signal and make your pass on level terrain with plenty of clearance
- If necessary, downshift for improved acceleration

DRIVING WITH AN AUTOMATIC OVERDRIVE TRANSMISSION

With certain automatic overdrive transmissions, towing – especially in hilly areas – may cause excessive shifting between overdrive and the next lower gear.

- To eliminate this condition and achieve steadier performance, overdrive can be locked out (see vehicle Owner Guide)
- If excessive shifting does not occur, use overdrive to optimize fuel economy
- Overdrive may also be locked out to obtain engine braking on downgrades
- When available, select Tow/Haul mode to automatically eliminate unwanted gear search and help control vehicle speed when going downhill

DRIVING WITH SPEED CONTROL

When driving uphill with a heavy load, significant speed drops may occur.

- An 8-14 mph speed drop will automatically cancel speed control
- Temporarily resume manual control through the vehicle's accelerator pedal until the terrain levels off

TIRE PRESSURE

- Underinflated tires get hot and may fail, leading to possible loss of vehicle control
- Overinflated tires may wear unevenly
- Tires should be checked often for conformance to recommended cold inflation pressures

SPARE TIRE USE

A conventional full-size spare tire is required for trailer towing (mini spare tires should not be used; always replace the spare tire with the road tire as soon as possible).

ON THE ROAD

After about 50 miles, stop in a protected location and double-check:

- Trailer hitch attachment
- Lights and electrical connections
- Trailer wheel lug nuts for tightness
- Engine oil – check regularly throughout trip

HIGH ALTITUDE OPERATION

Gasoline engines lose power by 3-4% per 1,000 ft. elevation. To maintain performance, reduce GVWs and GCWs by 2% per 1,000 ft. elevation.

POWERTRAIN/FRONTAL AREA CONSIDERATIONS

The charts in this guide show the minimum engine size needed to move the GCW of tow vehicle and trailer.

- Under certain conditions, however, (e.g., when the trailer has a large frontal area that adds substantial air drag or when trailering in hilly or mountainous terrain) it is wise to choose a larger engine
- Selecting a trailer with a low-drag, rounded front design will help optimize performance and fuel economy

NOTE: For additional trailering information pertaining to your vehicle, refer to the vehicle Owner Guide.

Photography, illustrations and information presented herein were correct when approved for printing. Ford Motor Company reserves the right to discontinue or change at any time the specifications or designs without incurring obligation. Some features shown or described are optional at extra cost. Some options are required in combination with other options. Consult your Dealer for the latest, most complete information on models, features, prices and availability.

Many of the recreational vehicles shown in this brochure are modified or manufactured by companies other than Ford Motor Company. Ford assumes no responsibility for such modifications or manufacturing.



Retailer Education & Training

For more vehicle information, please visit www.fordvehicles.com.