

2005+ Headlight Conversion

Parts List:

- Dfuser 9007 to 9008 Heavy Duty Headlight Harness kit with Relays
- Ford 2005+ Headlights (Left and right)
- Stainless Steel Headlight upper mounting kit (Screws, Washer, and clips)

Tools:

- Dremel Tool
- Philips Screw driver
- Socket and Ratchet to loosen bumper (19mm!)

Installation:

- Remove Front Grill
- Loosen the front 4 bolts by the hooks that hold the front bumper (Do not remove)
- Remove the 2 screws holding the turn signal assembly on each side
- Remove the turn signal assembly (Unplug light harness)
- Remove Headlight plugs and bulbs
- Remove Old Headlights (You will have with those, 2 clips visible and a hidden plastic clip)
- Start trimming (see pictures for reference)
- Test the headlights from proper fit
- Re-use the bottom screws for the turn signal assemblies to mount the new headlights on the bottom
- Use the provided SS screw kit to mount the headlights on the top
- Use the provided 9007 to 9008 HD kit to power the high and low beams
- Move the orange bulbs from the new headlights to the plugs on the old turn signal assemblies
- Re-use the turn signal and small lights from the previous assemblies to mount to the headlight
- Re-Install the grill
- Align the bumper and tighten the bolts



Left Cutout View



Bottom Cutout View



Full Cutout View



Top Cutout View



Right Headlight Installed



The Final Product.

For more Information, please visit our website: <http://www.dfuser.com>

Questions: Send email to Support@dfuser.com

dfuser.com
108 Evergreen Road
Georgetown, TX 78628-9500